

⚠️ WARNING

To reduce risk of serious injury from collapse, crush, laceration or pinch hazards:

- Read & follow safety information & instructions before use.
- Never allow a child to fold/unfold chair.
- Never allow a child under 3 years of age to use this chair. Use only with adult supervision
- Always make sure chair is locked in open position prior to use.
- Keep hands/fingers away from hinges and latches.
- Never allow a child to stand on chair seat.
- Maximum load capacity: 150 pounds
- Never use chair outdoors.

TO OPEN CHAIR



With one hand, depress the inner 2 latches and at the same time push down on the seat until the seat latch locks in place. You will hear a click/snap once locked open.

TO FOLD CHAIR



With one hand on the chair back, use the other hand to depress the seat outer 2 latches while pulling the seat front up until the chair locks in the folded (closed) position. You will hear a slight click/snap when locked folded.